

The Genuine. The Original.



**OVERHEAD DOOR
OF ATLANTA
404-872-3667
www.OverheadDoorAtlanta.com**

Allister/Pulsar Keypad

Reset default setting by pressing **ON/RESET** then **999#,999#**

Push **ON/RESET, 1234 * 1**


Select a 4 digit PIN number and enter it here _____

Enter **ON/RESET, 1234, #,1, (PIN No),(PIN No),#**

Find your door code by entering the switch positions from the inside of your transmitter,
+ = 1, 0 = 2, - = 3

Enter **ON/RESET, (PIN No), ##, 1 (door code)**

To operate your door press **ON/RESET, (PIN), *, 1**



MULTIPLE DOOR INSTRUCTIONS:

It is **NOT** recommended to use this keypad to open more than one door, but if you must open multiple doors with this keypad please code door #1 with the above instructions before attempting to code doors 2 and/or 3

Press **ON/RESET, (PIN No), *, 2** for door number 2
Find your door code by entering the switch positions from transmitter 2,
+ = 1, 0 = 2, - = 3

Enter **ON/RESET, (PIN No), ##, 2, (door code)**
To operate your door press **ON/RESET, (PIN No), *, 2**

Press **ON/RESET, (PIN No), *, 3** for door number 3
Find your door code by entering the switch positions from transmitter 3,
+ = 1, 0 = 2, - = 3

Enter **ON/RESET, (PIN No), ##, 3, (door code)**
To operate your door press **ON/RESET, (PIN No), *, 3**



works with these transmitters



**Visit our Showrooms in-
Greater Hall County,
Armour Drive-Atlanta**

